

PARAMETRIC BAGGAGE TAG DATA
CONCEPT
BAGTAG PRINTER/ RFID READER
EXTENSION

EDITION 2011

Document Number AEABTP_01.DOC

Last update: 24. March 2011



PARAMETRIC BAGGAGE TAG DATA CONCEPT

ABSTRACT

PARAMETRIC BAGGAGE TAG DATA CONCEPT

Revised:	27 February	1986	Original Issue 5/86	
	22 March	1988	Approved	
	19 January	1989	Rev. 2	p.5, p7, p11
	26 July	1989	Rev. 3	p.5
	03 July	1990	ATB 1	
	15. April	1991	Rev. 3	p.6, p.11
	18 September	1991	Approved	p.7
	01 March	1993	Rev. 5	p. 5
	06 September	1993	Rev. 6	p.10
	21 December	1993	Approved	p.10
	01 October	1994	Rev. 7	Logo/Format Code expansion
	01 November	1994	Approved	
	06 June	1995	Rev. 8	p.1, p.3. p.4, p.13
	06 November	1995	Approved	
	22 November	1999	Rev. 9 Approved	p.4 code 128
	21 st June	2001	Rev.10 Approved	colour printing, colour status, general status added, 2.2.3. code choice 7 deleted, 5.3.1 and 5.5.1 Note added
	26 August	2002	Rev. 11	2.2.3. barcode choice 7 added again, Note changed
	21 st June	2006	Rev. 12	Chapter 9, 10 & 11 added, BS, AV & CT commands, 5.1. clarified pcx logo
	15.March	2007	Rev. 13	RFID capabilities added in pectab & printing, SC, RC commands, Annex A&B
	2.October	2008	Rev.14.12	ES, EP,UC,UK commands ad-ded, CT up-dated. RFID #Vx 2 param added, Void example, SC#Nx and RI added/changed, 14.4. added, RCOK&2.2.3& AVOK ERRE & EP updated
1.October	2009	Rev. 15.5	BS updated, BTP with stock ID, BL & BC & MG added, new EP parameters added, RCOK updated, ERRS added, Annex C, PVOK updated	
11./30.November	2009	Rev. 15.6 / 15.7	PVOK amended, BL example added up- dated, RI updated, EP RFID default updated	
3.December	2009	Rev. 15.8	SQNI SQOK changed	
12.January	2010	Rev. 15.9	Fonts codepage added, 2.1 updated, EP#RFID & AnnexC removed, SC,BC,BLRCOK SQOK/SQNI updated	
12.November	2010	Rev. 16	RFID reader /Barcode reader device support added, AVOK, RIOK, SQOK, SQNI updated, tables updated	
16.December 16.January 27.January 27.February 14.March 24.March	2011	Rev. 16.1/2/3 Rev.16.4 Rev.16.5 Rev.16.6	CB/CBOK, TO/TOOK added, Pectab table updated, BEEP updated, BRF device name added throughout, single/multi user updated, EP PLATENERR added Ref added to PLATENERR, compaction code 00 added for RFID tags, ERRRC1 added EP AUTODETECT updated, TRUNCATE added	

***This document has been produced by the AEA Technical Group (ATG):
AIR FRANCE, BRITISH AIRWAYS, KLM, LUFTHANSA, SWISS AND BRUSSELS Airlines***

PARAMETRIC BAGGAGE TAG DATA CONCEPT

TABLE OF CONTENTS

1. DEFINITION OF THE PARAMETRIC BAG TAG DATA CONCEPT	1
RFID AUTO MODE	2
2. THE TABLE	3
2.1. Layout of the Header of the Table	3
2.1.1. Header	3
2.1.2. Table Number	3
2.1.3. Table Version	3
2.1.4. Continuation Character	3
2.1.5. Auto Increment Field Length	4
2.1.6. Colour Character	4
2.1.7. Tag Width	4
2.1.8. Mirror Point	4
2.1.9. Element Reference Character	4
2.1.10. Separator Character	4
2.2. Structure of the Body of the Table (element descriptor)	4
2.2.1. Element Number	5
2.2.2. Element Type	5
2.2.3. Element Choice	5
2.2.4. Mirror Indicator	5
2.2.5. Orientation/Video	6
2.2.6. Position vertical	7
2.2.6.1. Example of RFID Data	7
2.2.7. Position horizontal	8
2.2.8. Size Height	8
2.2.9. Size Width	8
2.2.9.1. Listing of Barcodes for Pectabs	9
2.2.9.2. Example of Barcode Definition	9
2.2.10. Common Data	10
2.2.10.1. Example of Common Data (incl. reference character)	10
2.2.11. Colour printing	11
2.2.12. Definition of coordinates	12
2.2.13. Example of the structure of a Table	14
3. PECTAB DOWN LINE LOADING	16
3.1. The table load function	16
3.1.1. Example of the PECTAB load message	16
3.2. Confirmation of PECTAB load message	17
3.2.1. Example of a confirmation message after a successful PECTAB load	17
3.2.2. Example of a confirmation message after an unsuccessful PECTAB load	17
3.2.3. Example of a confirmation message after an unsuccessful PECTAB load	17
3.3. The PECTAB cancellation function	17
3.3.1. Example of a confirmation of cancellation of PECTAB(s)	18
3.3.2. Example of a confirmation when PECTAB buffer contains no PECTAB(s)	18

PARAMETRIC BAGGAGE TAG DATA CONCEPT

3.4. The Pectab Status request	18
3.4.1. Example of a response on a status request	18
3.5. Illogical command	18
3.5.1. Example of an ERR2 message	18
4. BAG TAG PRINTING	19
4.1. Name of the Tag Data	19
4.2. Method	19
4.3. Bag Tag Data Message Concept	19
4.4. Examples of bag tag data message	20
4.4.1. Example 1	20
4.4.2. Example 2 (message with use of the continuation character)	21
4.5. Messages from the BTP to the host	21
4.5.1. Example of message 1 (print ok)	22
4.5.2. Various Examples of Successful Print/Encode Message with RFID Void indicator	22
4.5.2.1. Successful Print message - SC command set to J0 L0	22
4.5.2.2. Successful Print message - SC command set to J0 L1	22
4.5.2.3. Successful Print message - SC command set to J1 L0	23
4.5.2.4. Successful Print message - SC command set to J1 L1	23
4.5.2.5. Successful Print message - SC command set to J1 L1 – Intermediate Acknowledgement	23
4.5.2.6. Successful Print message - SC command set to J1 L1 – Intermediate Acknowledgement with Paper out inbetween	23
4.5.2.7. Partly Successful Print message - SC command set to J1 L1 – Intermediate Acknowledgement & too many voided tags	23
4.5.3. Example of message 2 (illogical command)	24
4.5.4. Examples of message 3 (incorrect field detected)	24
4.5.5. Example of message 5 (unsuccessful print)	24
4.5.5.1. Example of message 5 (unsuccessful print)	24
4.5.5.2. Example of message 5 (unsuccessful print) – Paper out with voided bagtags	25
4.5.5.3. Example of message 5 (unsuccessful print – voids exceeds parameter) RFID	25
4.5.5.4. Example of message 5 (voids exceeds parameter) RFID – SC command set J1	25
4.5.5.5. Example of message 5 (voids exceeds parameter) RFID – SC command set L1	26
4.5.5.6. Example of message 5 (voids exceeds parameter) RFID – SC command set J1 L1	26
4.5.5.7. Example of message 5 (Unsuccessful RFID encode from handheld reader/encoder)	26
4.5.6. Example of message 6 (PECTAB not available)	26
4.5.7. Example of message ERRS (Stock type not available)	26
5. LOGO DOWN LINE LOADING	27
5.1. Name of the LOGO data	27
5.2. The LOGO load function	27
5.2.1. Example of the LOGO load request	27
5.3. Confirmation of a LOGO load request	28
5.3.1. Example of a confirmation message after an successful LOGO load	28
5.3.2. Example of a confirmation message after an unsuccessful LOGO load	28
5.3.3. Example of a confirmation message after an unsuccessful LOGO load	28
5.4. The LOGO cancellation function	28
5.4.1. Example of a confirmation of cancellation of LOGO(s)	29
5.4.2. Example of a confirmation when BTP contains no LOGO(s)	29
5.5. The LOGO status request	29

PARAMETRIC BAGGAGE TAG DATA CONCEPT

5.5.1. Example of a response on a status request	29
5.6. Illogical command	29
5.6.1. Example of an ERR2 message	29
6. COLOUR STATUS	30
6.1. Colour status request	30
6.2. Example of a response on a colour status request	30
7. PROGRAM DOWN LINE LOADING	31
7.1. Method	31
7.2. Name of the PROGRAM data	31
7.2.1. The PROGRAM load function	31
7.2.1.1. Example of the PROGRAM load request	31
7.2.2. Confirmation of a PROGRAM load request	32
7.2.2.1. Example of a confirmation message after an successful PROGRAM load	32
7.2.2.2. Example of a confirmation message after an unsuccessful PROGRAM load	32
7.2.3. The program delete function	32
7.2.3.1. Example of a response on a delete program request	32
7.3. The PROGRAM-version request	32
7.3.1. Example of a response on a program version request	33
8. GENERAL STATUS REQUEST	34
8.1. Example of a response on a general status request	34
9. BIN / PAPER STATUS REQUEST	35
9.1. Example of a response on a bin/paper status request	35
10. AEA VERSION REQUEST	35
10.1. Example of a response on an AEA version request	35
11. THE HARDCODED TRANSACTION CODE LOAD FUNCTION	36
11.1. Example of confirmation of TRANSACTION CODE load function	36
12. BAGTAG PRINTER SET RFID CONFIGURATION	37
12.1. Set RFID configuration command	37
12.1.1. Example 1 of the Set RFID configuration command (all parameters)	38
12.1.2. Example 2 of the Set RFID configuration command (Julian Date)	38
12.1.3. Example 3 of the Set RFID configuration command (Time & Application ID)	39
12.1.4. Confirmation of a Set RFID configuration command	39
12.2. Reset RFID configuration command	39
12.2.1. Example of a response on a Reset RFID configuration command	39
12.3. Errors to the Set RFID configuration command	39
12.3.1. Example 1 of an error response on a Set RFID configuration command	40

PARAMETRIC BAGGAGE TAG DATA CONCEPT

12.3.2. Example 2 of an error response on a Set RFID configuration command	40
12.3.3. Example 3 of an error response on a Set RFID configuration command	40
12.3.4. Example 4 of an error response on a Set RFID configuration command	40
12.3.5. Example 5 of an error response on a Set RFID configuration command	40
12.3.6. Example 6 of an error response on a Set RFID configuration command	40
13. BAGTAG PRINTER CONFIGURATION QUERY	41
13.1. Example of a Printer Configuration query response	41
14. BAGTAG PRINTER ENVIRONMENT PARAMETERS	42
14.1. Introduction	42
14.2. Method	42
14.3. General handling	43
14.3.1. Single user	43
14.3.2. Single user with multi user context environment	43
14.3.3. Multi user with multi user environment	44
14.4. The “AEA Printer Environment” in CUPPS	44
14.4.1. Query Platform default environment - ES	44
14.4.2. Change Platform environment - EP	44
14.5. Printer Environment data	45
14.6. The “Printer Environment” status request	47
14.6.1. Single user	49
14.6.1.1. “Printer Environment” status request for current values	49
14.6.1.2. Example of a full response on a Printer Environment status request	49
14.6.2. Single user with multi user context	49
14.6.2.1. “Printer Environment” status request for default values	49
14.6.2.2. Example of a full response on a Printer Environment status request (default values)	49
14.6.2.3. “Printer Environment” status request for specific context	49
14.6.2.4. Example of a full response on a Printer Environment status request	49
14.6.3. Global user	50
14.6.3.1. “Printer Environment” status request for global context	50
14.6.3.2. Example of a full response on a Printer Environment status request	50
14.7. The “Printer Environment” change request	50
14.7.1. Single user	50
14.7.1.1. “Printer Environment” change request	50
14.7.1.2. Example of a full response on a Printer Environment change request	50
14.7.1.3. Example 1: error response to a Printer Environment change request (invalid keyword)	50
14.7.1.4. Example 2: error response to a Printer Environment change request (invalid content in keyword)	51
14.7.2. Single user with multi user context	51
14.7.2.1. “Printer Environment” change request (default values)	51
14.7.2.2. Example of a response on a Printer Environment change request (default values)	51
14.7.2.3. “Printer Environment” change request (specific UID)	51
14.7.2.4. Example of a full response on a Printer Environment change request (specific UID)	51
14.7.2.5. Example 1: error response to a Printer Environment change request (invalid keyword)	51
14.7.2.6. Example 2: error response to a Printer Environment change request (invalid content in keyword)	52
14.7.2.7. Example 3: error response to a Printer Environment change request (invalid content in multiple keywords)	52
14.7.2.8. Example 4: error response to a Printer Environment Status request (invalid airline, airline environment not previously defined with EP)	52
14.7.3. Global user	52
14.7.3.1. “Printer Environment” change request	52
14.7.3.2. Example of a full response on a Printer Environment change request	52
14.7.3.3. Example 1: error response to a Printer Environment change request (invalid keyword)	52

PARAMETRIC BAGGAGE TAG DATA CONCEPT

14.7.3.4. Example 2: error response to a Printer Environment change request (invalid content in keyword)	53
14.7.3.5. Example 3: error response to a Printer Environment change request (invalid content in multiple keywords)	53
14.7.3.6. Example 4: error response to a Printer Environment change request (no airline id – printer not in “Global user mode”)	53
14.8. Change Context	53
14.8.1. Example of a user creation or context selection command	53
14.8.2. Example of confirmation for a user creation or context selection	53
14.8.3. Example of confirmation of an unsuccessful creation or selection (out of memory)	53
14.8.4. Example of confirmation of an unsuccessful creation or selection (invalid airline)	54
14.8.5. Objects handling	54
15. CLEAR A USER ID	55
15.1. Single user	55
15.1.1. Example of clear user ID request	55
15.1.2. Example of message confirmation for a counter request	55
15.2. Single user with multi user context	55
15.2.1. Example of clear user ID request (all users)	55
15.2.2. Example of message confirmation for a counter request	55
15.2.3. Example of clear user ID request (specific user)	56
15.2.4. Example of message confirmation for a clear user ID request	56
15.2.5. Example of message after an unsuccessful request (invalid UID)	56
15.3. Multi user with multi user context	56
15.4. Global user	56
16. USER COUNTERS	57
16.1. Single user	57
16.1.1. Example of user counter request	57
16.1.2. Example of message confirmation for a counter request	57
16.1.3. Example of an unsuccessful counter request	57
16.1.4. Example of user counter reset request	57
16.1.5. Example of message confirmation for a counter request	57
16.2. Single user with multi user context environment	58
16.2.1. Example of counter request for cumulative user totals	58
16.2.2. Example of message confirmation for a cumulative counter request	58
16.2.3. Example of counter request for a specific user	58
16.2.4. Example of message confirmation for a counter request for a specific user	58
16.2.5. Example of an unsuccessful counter request	58
16.2.6. Example of user counter reset request for all users	58
16.2.7. Example of user counter reset request for a single user (which implies all users)	59
16.2.8. Example of message confirmation for a counter request	59
16.3. Multi user with multi user context	59
16.4. Global user	59
17. DEVICE INFORMATION	60
17.1. Device Information request	60
17.2. Device Information request response	60
17.2.1. Example 1 of message device information response	62
17.2.2. Example 2 of message device information response	62

18. THE BIN SETUP LOAD FUNCTION	63
18.1. Method	63
18.2. Example 1 for a BIN SETUP load function	63
18.3. Example 2 for a BIN SETUP /status load function	63
18.4. Example 3 for a BIN SETUP load function	64
18.4.1. Confirmation to a BIN SETUP load function	64
18.4.1.1. Example 1 of confirmation of a BIN SETUP load function (3 bin printer)	64
18.4.1.2. Example 2 of confirmation of a BIN SETUP load function (2 bin printer)	64
18.4.1.3. Example 3 of confirmation of a BIN SETUP load function (1 bin printer)	64
19. PRINT CONTRAST SET REQUEST	65
19.1. Method	65
19.1.1. Example 1 of a print contrast set request	65
19.1.2. Example 2 of a print contrast set request	65
19.2. Examples print contrast status / set response	66
19.2.1. Example 1of a response on a print contrast set request (3 bin printer)	66
19.2.2. Example 2 of a response on a print contrast set request (2 bin printer)	66
19.2.3. Example 3 of a response on a print contrast set request (2 bin printer)	66
19.2.4. Example 4 of a response on a print contrast set request (1 bin printer)	66
19.2.5. Example 5 of a response on a print contrast set request (1 bin printer)	66
20. BTP DEVICE STATUS REQUEST	67
20.1. Device Information request	67
20.2. Example of message Status response OK - SQOK	67
20.3. Example of message (unsolicited status from BTP) - SQNI	68
20.4. Example of message Status response OK – SQOK for BRF device	68
20.5. Example of message (unsolicited status from BRF DEVICE) - SQNI	69
21. DEVICE DISPLAY MESSAGE	70
21.1. Example of message 44 (Agent display message command)	70
21.2. Example of message 46 (display message processed)	70
22. BRF DEVICE MESSAGES TO THE HOST	71
22.1. Read in barcode Data – BCDI	71
22.2. Read in RFID Bagtag Data – RFDI	72
22.3. No RFID tag found in range of scanner – ERRNT	72
22.4. Multiple RFID tags found in range of scanner – ERRNM	72
22.5. Non conforming RFID tag found in range of scanner– ERRNI	72
22.6. RFID tag cannot be encoded – ERR5V00	73

PARAMETRIC BAGGAGE TAG DATA CONCEPT

22.7. RFID tag memory on chip - size exceeded – ERRC1	73
22.8. Example of tag encoded ok (print ok) - PROK	73
22.9. Example of message CBOOK (scanned data ignored + buzzer)	73
22.10. Example of message 48 (Time out value setting processed)	73
23. BRF DEVICE MESSAGES FROM THE HOST	74
23.1. BRF device Environment data	74
23.2. Example of message 16 (red light and buzzer/beep activated)	76
23.3. Example of message 47 (Time out value setting) - TO	76
23.4. Receipt printer handling for device	77
23.4.1. Output example	78
23.4.2. Receipt print handling RPMODE=BTP (Receipt Data RD in BTP message)	78
23.4.2.1. Receipt print message from host to BTP RFID Encoder with Receipt Printer facility	78
23.4.2.2. Bagtag RFID chip encoded receipt printed OK message	78
23.4.2.3. Bagtag RFID chip encoded receipt not printed OK message	79
23.4.3. Receipt print handling RPMODE=RD (Separate Receipt Data RD message)	79
23.4.3.1. Receipt print message from host to BTP with Receipt Printer facility	79
23.4.3.2. Receipt printed OK message from BTP with Receipt Printer facility	79
23.4.3.3. Receipt not printed message from BTP with Receipt Printer facility	80
ANNEX A: EXPLANATION RFID ENCODING STRUCTURE ACCORDING ISO	81
ANNEX B : SUMMARY OF BAGTAG PRINTER MESSAGES	82